





## Installation:

- 1- When it is desired to connect any fixed installation cable (TV, data cable) by directly taking it out from the case, the base is placed on the case by passing the cable through the slot on the base, as is shown in the picture.
- 2- The base is fixed by tightening the nail screws (6) by an appropriate screwdriver.
- 3- Cable is passed through the fixing setup and screws are tightened as much as the cable is not damaged.
- 4- The transparent pieces are fastened to their slots on the sideways of the frame, as shown in the picture.
- 5- The cable outlet slot behind the cover is opened by being broken.
- 6- After the cable is passed through the middle of the frame and placed just on the base, the cover is fixed via nails in order to complete the installation.

Note: In case of using the product as the Empty Frame Cover, the base is fixed to the case and the other pieces are installed.